

Little Giants

Washing machines

PW 6055 Plus**Performance specifications**

Load ratio: 5.5 kg
Drum volume: 54 l
Spin speed: 1400 rpm
g-factor: 526
Residual moisture: 50 %

Control system**PROFITRONIC L PLUS**

Electronic controls with high-end liquid-crystal display;
6 standard programmes and up to 18 special programmes available;
Arbitrary temperatures and spin speeds;
Simple navigation with multifunction selector;
4 direct-access keys to select favourites;
Programme customisation option;
Multi-language user interface (21 languages selectable);
24 h delay start;
Countdown indicator;
Drum lighting.

Drive

Asynchronous motor with frequency controls

Features

Stainless-steel suds container; 2 specialised heater elements;
Dump valve or drain pump; Hot and cold water connection (optional:
Alternative water supply);
Coin mechanism connection, Serial RS 232 interface, optical PC

Heating

Electric

Dispensing technology

Three-compartment front dispenser; Pre-equipped for connection of 4
liquid-dispenser pump.

Wash technology

Patented honeycomb drum;
Scoop-and-ladle technology;
Automatic load control;
Two-stage imbalance sensing.

Design

Robust spaceframe casing;
Optional front and side panels stainless steel or enamelled front and
sides in white, silver screen, machine lid with stainless steel;
Enlarged porthole(30 cm diameter);
Optional to combine washing machine and tumble dryer as a stack;
Dimensions: H x B x T: 85.0 x 59.5 x 71.5 cm.

Test certificates

VDE, EMV